



Instructions for use

FENNEK GRILL. stick together. grill wherever.

Made in Germany

1. General

Thank you for choosing our portable FENNEK grill. Included in the scope of delivery are: 1 rear wall, 2 side walls, 2 base plates, 1 coal grate, 1 grill grate, 1 handle, 1 cover plate, 1 assembly instructions, 1 Aluminum case for storage.

Please verify the completeness of your FENNEK grill prior to its first start-up. We do not accept any later complaints.



Important!

Please read the following information carefully before using this product, and keep the manual for future consultation!

2. Specifications

FENNEK, Model EAN 4260518570013

Measurements in mm W x D x H:

Product packaging: 301 x 197 x 42, dismantled in case: 295 x 193 x 25, assembled without case: 284 x 193 x 277

Grilling surface: 270 x 183

Gross weight: 3,100 g, Weight grill: 2,580 g, Weight case: 520 g

Material grill: Stainless steel, Material case: Aluminum

Surface grill: polished, Surface case: powder-coated

3. Assembly and start-up



Properly clean all parts prior to first use, in order to remove any potentially existing machining residues. It is recommended that FENNEK be started up with charcoal and properly heated through, before the grill is used for the first time to cook food.

Assembly please see enclosed instructions or watch the video on <http://www.fennek-grill.de/aufbau/> or <https://www.youtube.com/watch?v=4IWWVZG-Svk>

Once assembled, position FENNEK in its aluminum case on a level, clean, and heat-resistant surface.

Remove the coal grate and put up to 4 lighter cubes into the combustion chamber.

Put the coal grate back on and ignite the lighter cubes with the help of a BBQ lighter or extra long matches.

Add the desired amount of charcoal or briquettes. (Fill height upper edge of the lower ventilation slots)

Once the embers have reached the desired temperature, attach the grill grate, and place the food on top of it.

Attach the cover sheet, if it rains or if you want to reflect heat.

Warning: FENNEK may only be used for grilling and heating up food, such as meat, vegetables, or fish. Improper use may lead to bodily injury or damage to property.

4. Additional features

Handle: The handle also functions as a bottle opener, and its bottom piece can be used to scrape off any debris on the coal and grill grates.

Aluminum case: Functions as an underlay to protect the base from heat and dirt. The fold-up lid allows for additional wind protection.





Instructions for use

FENNEK GRILL. stick together. grill wherever.

Made in Germany

Warnings

Risk of burns

- Cover sheet and grill grate may only be adjusted by using the included handle.
- Only use adequate flammable material made of wood fiber, wood wool / wax, or kerosene-based fire starters. Do not use fuel paste, as it may leak and cause burns. Do not use other highly volatile fluids such as spirits or gasoline to ignite charcoal.
- Do not intend to move FENNEK while in use and if not entirely cooled off.
- Any grease or juices that drip down on the hot charcoal can create flames.
- Detach the handle after each use; never leave it attached to the grill grate.
- Do not move or touch FENNEK until all charcoal or briquettes are completely burned out, all embers are fully extinguished, and all parts are cool.
- Do not remove ashes until all charcoal or briquettes are completely burned out, all embers are fully extinguished, and all parts are cool.
- Do not clean any parts until all charcoal or briquettes are completely burned out, all embers are fully extinguished, and all parts are cool.
- Do not place FENNEK back into its aluminum case until all charcoal or briquettes are completely burned out, all embers are fully extinguished, and all parts are cool.

How to deal with fire

- In the case of burns: Immediately cool off burnt areas. It is recommended to see a doctor. In the case of higher-degree burns, call emergency services (emergency number varies from country to country).
- Never have a barbecue in the woods. FENNEK may only be used outdoors and in designated barbecue areas.
- Please keep in mind that there is always the risk of flying sparks that might cause bodily injury or damages to property.
- It is highly recommended to not start a fire or a barbecue in extremely dry weather conditions. Always comply with the applicable fire safety regulations.
- Never extinguish embers with water, as this might damage the sheets and cause shooting flames. Always allow embers to burn out, or extinguish them with sand. Always transport FENNEK in its aluminum case.

Other information

- FENNEK is intended for outdoor use only. Never operate it in enclosed rooms.
- FENNEK may only be used for personal purposes; any use for commercial purposes is prohibited.
- Never operate FENNEK under the influence of e.g. fatigue, alcohol, drugs, or medication.
- Keep children and animals in a safe distance away from the grill.
- When in use, a distance of at least 3 meters has to be maintained between FENNEK and any combustible materials. Furthermore, never block any emergency exits, doors, or similar exits.

5. Maintenance and care

It is recommended to regularly clean FENNEK, in order to avoid any grease deposits, which could lead to grease fires. **Do not clean the grill until all charcoal or briquettes are completely burned out, all embers are fully extinguished, and all parts are cool.** It is recommended to roughly clean all parts by wiping them off with paper. The parts can then be put into the dishwasher for proper cleaning. Before the next use, please ensure that there are no residues from cleaners. Please do not clean the case with pan scratchers or abrasive cleaners in order to avoid scratches. **Caution:** Parts can have sharp edges.





Instructions for use

FENNEK GRILL. stick together. grill wherever.

Made in Germany

6. Safety information

CAUTION:



- FENNEK may not be operated by children and people with restricted psychological and/or physical abilities. People with restricted abilities as well as animals must maintain an adequate safety distance away from FENNEK.
- Improper use can lead to burns and injuries from getting jammed, crushed or cut. This applies to all parts as well as the aluminum case. Always follow the assembly instructions and observe the helpful hints and notes in the instructions for use.
- Always wear barbecue mitts and an apron, and use proper barbecue tools for positioning and turning the food.
- Fluids and other substances, especially combustible materials, can lead to deflagration or shooting flames. Never add such substances to embers or food.
- The burning of any material always causes smoke, and thus, creates carbon monoxide, which can lead to smoke poisoning and death. Never use FENNEK in enclosed rooms. FENNEK is designed for outdoor use only.

A first aid kit as well as a fire extinguisher should always be closeby when having a barbecue.

7. Service

- The stainless steel plates might slightly warp due to inconsistent heat expansion.
- The impact of heat stress on the material can cause discoloration.
- Burning resinous or wet firewood can result in black discoloration that might burn into the product permanently.
- Discoloration and traces of usage, such as scratches or slight warps of the plates, do not affect the function of the grill and do not constitute a claim under the warranty.
- No changes or modifications may be made to the FENNEK grill. Any such changes or modifications may pose a potential safety hazard.
- Repairs may only be executed by the manufacturer.

On request, all parts are available as spare parts. Please contact:

WWS Metallformen GmbH, Im Gereut 10, 76770 Hatzenbühl, Germany, info@wws-metallformen.de, Phone: 0049-(0)7275-989500

8. Disposal

Always keep the environment in mind: The packaging as well as the layer pads can be thrown into your paper waste bin or be disposed at your local paper collection point. Aluminum and other metals are valuable commodities. Please take them to your local recycling center or depot, or to one of the numerous scrap yards. Thank you!

Please contact the manufacturer, if you have any questions, suggestions, or complaints. For contact information, please visit:



www.fennek-grill.de,



<https://www.facebook.com/fennekgrill>,



[fennekgrill](https://www.instagram.com/fennekgrill)

